


Silver Solutions
GENERATORS . MONITORING & SWITCHING TECHNOLOGY

-Solar off-grid system -Automatic Changeover Switch

Cell: 072 644 2844 / 065 941 1980
Email: peter@sssolar.co.za Web: www.sssolar.co.za



5KW GRO 3.6 LITHIUM LITE **R64 750.00** including installation

: 5KW-BP10

THIS PACK INCLUDES:

- 1 x 5KW GROWATT 48V INVERTER
 - 1 x 3.6KWH DYNESS BATTERY 48V
 - 3x550W Canadian Panels
 - 1 x DC DISCONNECTOR
 - 1 x AC PROTECTION BOX
 - 2 x 35mm BATTERY CABLE
 - 4 x 35mm LUGS
 - 2x 20mm cable 4mm
- COMPLETE MOUNTING SYSTEM FOR TILE/IBR ROOF



Start by adding up the running watts of everything you might power at the same time.

Next pick the device with the highest running watts, and add its starting watts to the previous total.

Now you have the total amount of watts you need from your inverter generator.

Wattage Chart

Light Bulbs	Radio	Television	Computer	Laptop Computer	Cellular Phone	Microwave
Starting Watts: 50 - 150 Running Watts: 50 - 150	Starting Watts: 100 - 200 Running Watts: 100 - 200	Starting Watts: 150-500 Running Watts: 150-500	Starting Watts: 800 Running Watts: 800	Starting Watts: 200 Running Watts: 200	Starting Watts: 25 Running Watts: 25	Starting Watts: 1000 Running Watts: 1000
Coffee Maker	Slow Cooker	Blender	Hand Drill	Reciprocating Saw	Chainsaw	Electric Fan
Starting Watts: 800 - 1000 Running Watts: 600 - 1000	Starting Watts: 250 Running Watts: 250	Starting Watts: 850 Running Watts: 400	Starting Watts: 1000 - 1500 Running Watts: 400 - 600	Starting Watts: 960 Running Watts: 960	Starting Watts: 1200 Running Watts: 1200	Starting Watts: 600 Running Watts: 200